# LuminOx O<sub>2</sub> Sensors

## Luminescence-based Optical Flow-Through Series



- Luminescence–based optical technology, NOT electrochemical
- Contains no hazardous materials; RoHS & REACH compliant
- Connects directly to a microcontroller without any additional circuitry
- Factory calibrated
- High accuracy, fast response
- Maintenance free<sup>a</sup>



#### Housing



## Supply Voltage



## Operating Temp



#### Output Digital



#### Response Time



#### BENEFITS

- Compact, flow-through housing with sealed base
- Low power, long life due to non-depleting sensing principle
- Low cost

#### **✓** OUTPUT VALUES<sup>b</sup>

Oxygen range 0—25%  $O_2$  Oxygen pressure range 0—300mbar pp $O_2$ 

Response time T90 < 10s (typical)

Accuracy

ppO<sub>2</sub> < 2% FS
Temperature Indication only
Pressure ±5mbar

O<sub>2</sub> Determined by ppO<sub>2</sub> &

pressure accuracy

Resolution

 $\begin{array}{ccc} ppO_2 & 0.1 mbar \\ Temperature & 0.1 ^{\circ}C \\ Pressure & 1 mbar \\ O_2 & 0.01 \% \\ \\ Lifetime & > 5 years \end{array}$ 

### TECHNICAL SPECIFICATIONS

Supply voltage (Vs)  $4.5-5.5V_{DC}$ 

Supply current (Is) <7.5mA (streaming one

sample per second),

<20mA Peak

1.0 litre/min

Output Type 3.3V TTL level USART

Temperature

Maximum flow rate

Operating: -30°C to +60°C

Storage: -30°C to +60°C

Humidity 0—99% Rh (non-condensing)


Barometric pressure range 500—1200mbar

Need help? Ask the expert

0755-83680810

and ask for "Technical"






 At ambient conditions. All performance measurements are at STP unless otherwise stated. Following extreme temperature fluctuations, re-calibration may be required.

### OUTLINE DRAWING


**SENSOR CONSTRUCTION** 

All dimensions shown in mm. Tolerances = ±0.5mm



NOTE: 4.5mm OD push-fit tubing connectors.





Pin	Designation
1	Vs (+5V)
2	GND (0V)
3	3.3V USART Sensor Transmit
4	3.3V USART Sensor Receive

**CONNECTION:** Four gold-plated pins (0.64mm<sup>2</sup>) on a 2.54mm grid for PCB mounting via sockets or hand soldering using no-clean flux.

NOTE: Do NOT put the sensor through a PCB washing process.

**NOTE:** Always apply power to sensor pins 1 and 2 before attempting to communicate on pins 3 and 4.



The sensor should be treated as an electronic component and handled using the correct ESD handling precautions.




Do not exceed maximum ratings and ensure sensor(s) are operated in accordance with their requirements.

Carefully follow all wiring instructions. Incorrect wiring can cause permanent damage to the device.

Do NOT use chemical cleaning agents.

Failure to comply with these instructions may result in product damage.



## ORDER INFORMATION

Specify the part number below when ordering:

L O X - 0 2 - F

#### INFORMATION

As customer applications are outside of SST Sensing Ltd.'s control, the information provided is given without legal responsibility. Customers should test under their own conditions to ensure that the equipment is suitable for their intended application.

**General Note:** SST Sensing Ltd. reserves the right to make changes to product specifications without notice or liability. All information is subject to SST Sensing Ltd.'s own data and considered accurate at time of going to print.



